

Footman Loop Kit Installation Instructions

- 1) Find the ideal location on the railing of your pontoon to mount your Footman Loop
- 2) Mount the #2 Phillips bit in your drill
- 3) Hold the Footman Loop in the desired location on the railing
 - If you have a clamp It may be helpful to hold the Footman Loop in place while you are putting in the screws
- 4) Place one of the provided screws on the end of the #2 Phillips bit
- 5) Place the point of the screw in one of the holes of the Footman Loop
- 6) With slight pressure on the screw from the drill start the drill turning
- 7) Continue to apply slight pressure to the screw with the drill and continue drilling until the screw drills a hole through the railing
- 8) Snug the screw up tight to the Footman Loop and railing
 - Be careful when snugging the screw tight that you do not strip the hole in the railing (the railing material is thin)
- 9) Repeat steps 3-8 with the second provided screw



Warning! Preapplied thread locker is Loctite QuickTape 249 Contains Methacrylate esters. May cause allergic skin reaction. May cause eye skin and respiratory irritant. Avoid contact with skin and eyes. Use only with adequate ventilation. Wear eye protection and gloves. For skin contact wash thoroughly with soap and water. For eye contact flush with water for 15 minutes. Get medical attention for any eye or internal contact. KEEP AWAY FROM CHILDREN. MSDS is available at www.loctite.com